

Eddie Marine Fabricated Foot Throttle Installation Instructions

- 1.) Install the cable end, return spring, and cable mount onto the cable as shown. Do not install the stud into the cable mount at this time.
- 2.) Mount the rocker mount to the Stringer Mount Bracket.
- 3.) Attach the Rocker to the rocker mount.
- 4.) With your seat and steering wheel installed, clamp the assembly to the stringer.
- 5.) Move the assembly as needed to establish a comfortable operating position.
- 6.) Drill holes to mount the pedal to the rocker.
- 7.) Attach the cable rod end to the arm on the rocker.
- 8.) Place the pedal in a comfortable position when operating the boat at idle.
- 9.) Clamp the cable stop to the stringer mount to hold the pedal in this position.
- 10.) Push the pedal to the full throttle position and determine your comfort level at this point. Make sure that the pedal does not “go over center” causing stress on the cable.
- 11.) Adjust the position of the cable mount until you achieve correct operation and comfort at both positions. You may have to compromise comfort in one or both points to get optimum performance.
- 12.) Mark the cable stop position and drill it for the mounting stud.
- 13.) Using locktite, install the stud into the cable mount and attach to the stringer mount bracket.
- 14.) Permanently attach the stringer mount bracket to the stringer using nylock nuts and large back up washers.

