500-78 TRIM TAB DRILL TEMPLATE

Cut along the outside edge of this template and tape to your transom (consult the hull manufacturer for the recommended location). Center punch and drill the holes according to their specified size. Fasten securely with 3/8" flat head screws and nylon locking nuts. To prevent leaks, seal all fasteners and trim line bulkhead fittings with the appropriate silicone sealant.



Eddie MARINE, INC.
11479 Sixth Street, Rancho Cucamonga, CA 91730 • 909-945-2830 • Fax 909-945-9293 www.eddiemarine.com